



## CMCP-LVDT-51A

### Linear Variable Differential Transformer Installation Manual

#### Mechanical:

The CMCP-LVDT-51A must be mounted to a stable mounting surface on the turbine foundation at the unpinned end of the turbine casing; close enough for the extension rod to reach the casing. Insert the core shaft (the shortest of the two (2) shafts provided) into the transducer, with the end marked away from the connector. Attach the connecting rod to the core. Adjust the mounting block to achieve the desired position, then tighten the clamp screws. Bolt the CMCP-LVDT-51A in place through the four mounting holes, and secure the shaft to the turbine case. If using the spring loaded mechanism, trim the shaft to desired length.

#### Connection To Monitoring System:

Refer to the monitor manual for specific details and requirements of the monitor. The following procedure applies to the CMCP-548 Case Expansion Transmitter.

1. Connect transmitter **Common "- Terminal"** to the CMCP-LVDT-51A terminal with the LVDT **Green** lead labeled **Output Low**
2. Connect the transmitter **Input "+ Terminal"** to the CMCP-LVDT-51A terminal with LVDT **White** lead labeled **Output Signal**.
3. Connect **+24 VDC Power From External Power Supply** to the CMCP-LVDT-51A terminal with the **Black** lead.
4. Connect **Power Supply Common** to the CMCP-LVDT-51A terminal with the **Red** lead.

#### Alignment:



1. If monitor power connection has not been made, a 24 Vdc power source is required. Connect "+" to the red lead terminal, and "-" to the black lead terminal.
2. Connect a DC voltmeter across the CMCP-LVDT-51A terminals with white and green leads.
3. Final positioning of the core must be performed when the turbine is at ambient temperature. With the turbine at ambient temperature, apply power to the LVDT. As the core is moved from one end of the LVDT cylinder to the other, the output voltage will go from maximum (5 VDC), to minimum (0 VDC). It is recommended that the core position be set just within the maximum limit at the end away from the direction the core will move as the turbine expands to make the LVDT's entire range available for monitoring as the turbine expands. To set the core's position, loosen set screw, adjust the connecting rod by the inner rod until the desired output voltage is obtained, tighten set screw.



Condition Monitoring Custom Products

### CMCP-LVDT-51A

#### Linear Variable Differential Transformer Installation Manual



[www.cmcweb.com](http://www.cmcweb.com)

*Although care has been taken to assure the accuracy of the data compiled in this publication, SKF CMCP does not assume any liability for errors or omissions. SKF CMCP reserves the right to alter any part of this publication without prior notice.*

(5/3/01) Copyright © 1999-2001 by SKF CMCP

ALL RIGHTS RESERVED