



- Mounting Instructions:
1. Mount CMCPT1000 using the two small and one large mounting standoffs as shown.
 2. Using the three provided 1/4"-28 mounting bolts secure the CMCPT1000 to the base of the machine.
 3. Apply a medium strength thread locker to the mounting bolts.
 4. Torque mounting bolts to 50 In.-Lbs.
 5. See CMCPS500 Series Manual for Wiring Instructions

THIS DOCUMENT IS PROPERTY OF STI AND CANNOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS WITHOUT WRITTEN CONSENT FROM STI. THIS DOCUMENT CANNOT BE TRANSMITTED OR SENT THROUGH ANY INTERNET PROTOCOL, FROM STI.

REV	DATE	CHANGE / DESCRIPTION
1		
2		
3		
4		
5		

CUSTOMER		STI	
LOCATION		ORDER NO.	
ORDER NO.		DATE ORDERED	
QUANTITY		TELEPHONE	
REVISIONS		FAX	
DATE		EMAIL	
BY		STI	
CHKD		DATE	
APP'D		SCALE	

STI
STI Vibration Monitoring
 League City, Texas

Scale: 1:1