

## Condition Monitoring Custom Products

"Vibration Monitoring and Machine Protection Systems"

2911 S. Shore Blvd., Ste. 170, League City, TX 77573 Phone: 281.334.0766 Fax: 281.334.4255

# CMCP625 2-Pin to BNC Adapter

#### Features

•

- 2-Pin to BNC Adapter
- Potted backshell and Interfacial O-Ring

### Description

The CMCP625 Adapter converts the MS, 2-Pin 5015 connector found on most industrial accelerometers to BNC. The adapter comes with a completely potted metal backshell and interfacial O-ring for positive sealing to the accelerometer. The CMCP625 may be used to convert permanently mounted accelerometers to a BNC connector or to connect BNC/BNC cables to industrial accelerometers.



#### **Ordering Information:**

CMCP625

2-Pin to BNC Adapter

www.cmcpweb.com

Although care has been taken to assure the accuracy of the data compiled in this publication, SKF CMCP does not assume any liability for errors or omissions. SKF CMCP reserves the right to alter any part of this publication without prior notice. (5/3/01) Copyright © 1999-2001 by SKF CMCP ALL RIGHTS RESERVED